## OPERATING AND PROGRAMMING INSTRUCTIONS Horizon Lock Range:- 3950-----



		MOD	Е				
FUNCTION	PUBLIC	PRIVATE	Milita	KEY SEQUENCE			NOTES
MASTER CODE FUNCTIONS - FO	R ST	EPS	1-3	PLEASE ENTER THE F	RELEVA	NT NUMBERS IN THE SEQUENCE	SHOWN BELOW (EG. STEP1STEP2STEP3)
				STEP 1	STEP 2	STEP 3	
CHANGE MASTER CODE	1	1	1	[logo] [Old Master Code]	01	[New Master Code] [New Master Code]	MASTER CODE IS EIGHT DIGITS
SET / CHANGE SUB-MASTER CODE	1	1	1	[logo] [Master Code]	03	[New Sub-Master Code]	SUB-MASTER CODE IS SIX DIGITS
DELETE SUB-MASTER CODE	1	1	1	[logo] [Master Code]	07		DELETES SUB-MASTER CODE
SET / CHANGE <b>TECHNICIAN</b> CODE	1			[logo] [Master Code]	10	[New Technician Code]	TECHNICIAN CODE IS SIX DIGITS
DELETE <b>TECHNICIAN</b> MODE	1			[logo] [Master Code]	11		DELETES TECHNICIAN CODE
CHANGE <b>USER</b> CODE		1		[logo] [Master Code]	02	[New User Code]	USER CODE IS FOUR OR SIX DIGITS
SET SINGLE USER PRIVATE MODE - FOUR DIGIT CODE	1		1	[logo] [Master Code]	09	[New Four Digit User Code]	SETS LOCK INTO FOUR DIGIT PRIVATE MODE - SINGLE USER ACCESS
SET MULTI-USER PRIVATE MODE (SIX DIGIT CODES)	1	1		[logo] [Master Code]			SETS LOCK INTO MULTI-USER MODE - NO USERS ARE ACTIVE INITIALLY
SET PUBLIC MODE - FOUR DIGIT CODE		1	1	[logo] [Master Code]	08		SETS LOCK INTO FOUR DIGIT PUBLIC MODE
SET AUDIBLE BUTTONS ON	1	1	1	[logo] [Master Code]	12		LOCK WILL BEEP ON EACH BUTTON PRESS
SET AUDIBLE BUTTONS OFF	1	1	1	[logo] [Master Code]	13		LOCK WILL OPERATE SILENTLY
SET UNSUCCESSFUL CODE LOCKOUT ON	1	1	1	[logo] [Master Code]	24		KEYPAD IS DISABLED FOR A SHORT TIME FOLLOWING FIVE
							INCORRECT ENTRY ATTEMPTS
SET UNSUCCESSFUL CODE LOCKOUT OFF	/	1	/	[logo] [Master Code]	25		KEYPAD DISABLE IS TURNED OFF
SET <b>TIMER AUTO-UNLOCK</b> ON & SET TIME	1			[logo] [Master Code]	16	[3 Digit Time Code]	AUTOMATICALLY OPENS LOCK AFTER SET TIME PERIC SEE NOTES ON TIMERS BELOW.
SET <b>TIMER AUTO-UNLOCK</b> OFF	1			[logo] [Master Code]	17		UNIT WILL NO LONGER OPEN AUTOMATICALLY
SET <b>AUTO-TIMED CODE CANCEL</b> ON & SET TIME	1			[logo] [Master Code]	26	[3 Digit Time Code]	DISABLES USER CODE AFTER SET TIME PERIOD. SEE NOTES ON TIMERS BELOW.
SET AUTO-TIMED CODE CANCEL OFF	1			[logo] [Master Code]	27		UNIT WILL NO LONGER CANCEL USER CODE
SET <b>RAS</b> MODE	1	1	1	[logo] [Master Code]	20	[Serial Number]	REMOTE ALLOCATION SYSTEM - CAN ONLY BE USED WITH ON-LINE SOFTWARE
SET SINGLE USE RAS MODE	1	1	1	[logo] [Master Code]	22	[Serial Number]	REMOTE ALLOCATION SYSTEM - CAN ONLY BE USED WITH ON-LINE SOFTWARE
OPEN LOCK AND DELETE USER CODE	1			[Master Code]			MASTER CODE IS EIGHT DIGITS
OPEN LOCK	1	1	1	[Master Code]			MASTER CODE IS EIGHT DIGITS
CLOSE LOCK	_	1	1	[master oode]			PUSH HANDLE BACK INTO UNIT
02002 200.1				SUB-MAS	STER C	CODE FUNCTIONS	
CHANGE <b>SUB-MASTER</b> CODE	1	1	1	[logo] [Sub-Master Code]	03	[New Sub-Master Code] [New Sub-Master Code]	SUB-MASTER CODE IS <b>SIX DIGITS</b>
CHANGE USER CODE		1		[logo] [Sub-Master Code]	02	[New User Code]	USER CODE IS FOUR DIGITS
OPEN LOCK AND DELETE USER CODE	1			[Sub-Master Code]			SUB-MASTER CODE IS <b>SIX DIGITS</b> .
OPEN LOCK		1	1	[Sub-Master Code]			SUB-MASTER CODE IS <b>SIX DIGITS</b> .
CLOSE LOCK	_	1	1	[			PUSH HANDLE BACK INTO UNIT
02002 200.		L.		TECHNIC	CIAN C	ODE FUNCTIONS	1 00.1111 HIDEE B. (01.1111 0 01.11
OPEN LOCK AND RETAIN USER CODE	1			[Technician Code]			TECHNICIAN CODE IS SIX DIGITS
OPEN LOCK		1	1	[Technician Code]			TECHNICIAN CODE IS SIX DIGITS
CLOSE LOCK	1	1	1				PUSH HANDLE BACK INTO UNIT
				USEF	RCODE	FUNCTIONS	
CHANGE <b>USER</b> CODE		1		[logo] [User Code]	02	[New User Code] [New User Code]	USER CODE IS FOUR DIGITS
OPEN LOCK	1	1		[User Code]			USER CODE IS FOUR DIGITS
OPEN LOCK	<b>—</b>	<b>'</b>	1	[Access Code]			ACCESS CODE IS TWO DIGIT USER REFERENCE
	-		•				FOLLOWED BY FOUR DIGIT USER CODE
CLOSE LOCK	1			[User Code] [User Code]			WHEN <b>DOUBLE</b> USER CODE ENTRY MODE IS SET
CLOSE LOCK		1	1	FUNCTIONS DE	OLUBI	NG NO AUTHODISATION	PUSH HANDLE BACK INTO UNIT
BATTERY CHECK	1		1	[logo] [logo]	.QUIKII	NG NO AUTHORISATION	REPLACE BATTERIES IF RED LIGHT SHOWS
						TIME CODE EXAMPLES	
NOTES				TIMER FUNCTIONS TIME CODE	001	TIME CODE EXAMPLES  1 MIN	
				TIME CODE	010	1 MINS	-
				TIME CODE	030	1/2 HR	
				TIME CODE	060	1 HR	
				TIME CODE	480	8 HRS	
				TIME CODE	720 999	12 HRS 16 HRS 39 MINS ( MAXIMUM )	-
						APPROVIMATE ±/= 10%	

ALL TIMES ARE APPROXIMATE +/- 10%